



Instant Glass Frosting

Ph: (03) 9886 1777

Mob: 0424 908 301

Email: info@instantglassfrosting.com.au

Web: www.instantglassfrosting.com.au

DIY Glass Frosting Fitting Instructions

Install on the INSIDE of the glass except if dogs or small children are likely to scratch at the material.

1. Prepare surface: Clean & scrape if necessary. It is important that there is no dust, paint flecks, hairs etc.
2. Have ready tools to fit: Spray bottle filled with warm soapy water; Smoothing Tool & Frosted Film.
3. Peel away frosted film from its backing (you may need 2 people to handle a large sheet).
4. Spray water mixture onto the STICKY side of the frosted vinyl and onto the GLASS.
5. When everything is wet & slippery, position the frosted material onto the glass surface and move into best position (within window frame if necessary).
6. Using your smoothing tool, start from the middle and smooth to the edges, removing all bubbles of air and water. **DO THIS STEP THOROUGHLY** as any small bubbles will be visible once dry.
7. Once all water has been squeezed out from under the frosted film, it will begin to adhere permanently.
8. If necessary, use a sharp Stanley knife to trim any edges that are not quite right.
9. Frosted film may take up to 6 hours to dry completely depending on environment.

If you require assistance, please do not hesitate to call us on (03) 9886 1777.